

JAW LIFTER INSTALLATION INSTRUCTIONS

1. Install the L-shaped aluminum bracket onto the fork crown.
2. Assemble the aluminum tube body by connecting the sections with the provided M6 bolt.
Make sure the VLCmade logo faces forward.
3. Attach the L-shaped bracket to the left side of the J-shaped aluminum body using one struts bolt, a 4mm aluminum spacer, and an M6 hex nut.
4. Adjust the position and height of the aluminum body as needed.
(The L-shaped bracket can be slightly bent for fine tuning.)
5. Secure the aluminum body to the fork using two struts bolts, 4mm aluminum spacers, M6 hexnuts, and the 300mm aluminum legs.
6. Trim any excess length from the L-shaped bracket and the 300mm aluminum legs for a clean finish.

